

GENERAL PURPOSE DISINFECTANT-READY HOUSING DEVICES CLEANING GUIDE



Honeywell

CLEANING GENERAL PURPOSE DISINFECTANT-READY HOUSING DEVICES

As our global community is preparing to get back to work, we all have a heightened sensitivity to bacteria and virus transmission.

Organizations whose employees use Productivity Devices in warehousing and DCs, retail, transportation and logistics, direct store delivery, healthcare and more are implementing safety protocols that affect millions of workers. Because many of these devices are shared from one shift to the next among workers, health experts recommend that organizations adopt protocols for routine cleaning and disinfecting of devices for employee health and safety.

In response, Honeywell is introducing a new family of Disinfectant-Ready Housings (DRH) devices for general purpose use. These devices are specifically designed to tolerate regular cleaning on a daily basis with harsh, disinfectant chemicals without any adverse damage or compromising the integrity of the device.

This guide provides advice and approved instructions on how to clean your Honeywell general purpose devices with disinfectant-ready housings.



HOW ARE HONEYWELL DEVICES WITH DRH DIFFERENT FROM THOSE WITH STANDARD HOUSINGS

Let's take a closer look at some of the differences between non-disinfectant-ready housing and disinfectant-ready housing exteriors.

Non-Disinfectant-Ready Device Housing

Non-disinfectant-ready housing hardware is traditionally housed in amorphous plastics. These plastics, including polycarbonate/acrylonitrile-butadiene-styrene (PC/ABS), are usually chosen because they can be easily manufactured.

Housings made of PC/ABS comprise a loosely packed structure that makes it easier for chemicals to penetrate the plastic. Repeated use of chemical cleansers may cause discoloration, swelling and hardening and cracking of rubber and certain plastics after prolonged and repeated use.

These cracks can lead to hardware failure, which increases the total cost of ownership by increasing downtime and repair/replacement costs.

Disinfectant-Ready Housings for General Purpose Devices

Honeywell was the first company in the barcode scanning industry to introduce disinfectant-ready housings. Honeywell DRHs for general purpose devices can stand up to the demands of cleaning protocols as a result of the heightened sensitivity.

Devices made with Honeywell DRHs have passed rigorous, continuous chemical exposure tests for over 500 hours. Honeywell DRHs are built to withstand multiple cleanings per hour, every day, with Honeywell-approved cleaning solutions.

Honeywell general-purpose products with DRHs, in most cases, meet the same environmental performance and drop-and-tumble specifications as defined for non-DRH versions. Consult product datasheets for any exceptions.

GENERAL-PURPOSE PRODUCTS AVAILABLE WITH DISINFECTANT-READY HOUSING

The Honeywell products with disinfectant-ready housing options that are included in this cleaning guide include:

Barcode Scanners

- Xenon™ XP 1950g
- Xenon XP 1952g-bf
- Voyager™ XP 1470g
- Voyager XP 1472g
- Genesis XP 7680g
- Xenon Ultra 1960g
- Xenon Ultra 1960li
- Xenon Ultra 1962g
- Xenon Ultra 1962li
- Xenon Ultra 1962g Battery-Free

Mobile Printers

- RP2 Series

Desktop Printers

- PC43d
- PC43k
- PC43t
- PC45d
- PC45t

Mobile Computers

- CT30 XP
- CT37
- CT40 XP
- CT40
- CT60 XP
- CK65
- ScanPal™ EDA51

Note: If you are unsure whether your device has disinfectant-ready housing, contact your Honeywell representative.

PRODUCTS AVAILABLE WITH DISINFECTANT-READY HOUSINGS:



Xenon™ XP 1950g
Xenon XP 1952g - bf



Xenon Ultra 1960g/li
Xenon Ultra 1962g/li
Xenon Ultra 1962 Battery-Free



Voyager™ XP 1470g
Voyager XP 1472g



Genesis XP 7680g



PC43d



PC43k



PC43t



PC45d



PC45t



CT30 XP



CT37



CT40
CT40 XP



CT60 XP



CK65



ScanPal™ EDA51



RP2 Series

HOW TO CLEAN HONEYWELL GENERAL-PURPOSE PRODUCTS WITH DISINFECTANT-READY HOUSING

The following cleaning solutions may be used with each category of Honeywell general purpose devices with disinfectant-ready housing.

APPROVED CLEANING SOLUTIONS

MOBILE COMPUTERS, SCANNERS AND MOBILE PRINTERS WITH DRH (Excludes Desktop Printers and CK65 and CT60XP Mobile Computers)

3% Hydrogen Peroxide and 97% Water Solution	Gentle Dish Soap and Water	Sani Professional® Disinfecting Multi-Surface Wipes
Alcowipe®	Isopropyl Alcohol 55%	Sani-Cloth® AF3 Germicidal Disposable Wipe
Azowipe™	Isopropyl Alcohol Wipes 70% (IPA 70)	Sani-Cloth Bleach Germicidal Disposable Wipe
Clorox® Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes	Medical Hydrogen Peroxide 3%	Sani-Cloth HB Sani-Germicidal Disposable Wipe
Clorox Healthcare Multi-Surface Quat Alcohol Wipes	Medicinal Alcohol 75%	Sani-Cloth Plus Germicidal Disposable Cloth
Dimension™ 256 Neutral Disinfectant Cleaner	Medipal® Alcohol Wipes	Sani-Hands® Instant Hand Sanitizing Wipes
Dimethyl Benzyl Ammonium Chlorides 0.125%	Oxivir® Tb Wipes	Sodium Hypochlorite 0.55%
Dimethyl Benzyl Ammonium Chlorides 0.14%	PDI Easy Screen® Cleaning Wipe	Super Sani-Cloth Germicidal Wipe
Ethyl Alcohol 54%-66v/v + N-Propanol 9% -11% v/v	Peracetic Acid Solution 0.2%	Viraguard®
Formula 409® Glass and Surface Cleaner	Progressive Products WipesPlus®	Virex® II 256 One-Step Disinfectant Cleaner

CT37 MOBILE COMPUTERS WITH DRH

3% Hydrogen Peroxide and 97% Water Solution	Gentle Dish Soap and Water	Sani Professional Disinfecting Multi-Surface Wipes
Alcowipe	Isopropyl Alcohol 55%	Sani-Cloth AF3 Germicidal Disposable Wipe
Azowipe	Isopropyl Alcohol Wipes 70% (IPA 70)	Sani-Cloth Bleach Germicidal Disposable Wipe
Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes	Medical Hydrogen Peroxide 3%	Sani-Cloth HB Sani-Germicidal Disposable Wipe
Clorox Healthcare Multi-Surface Quat Alcohol Wipes	Medicinal Alcohol 75%	Sani-Cloth Plus Germicidal Disposable Cloth
Dimension 256 Neutral Disinfectant Cleaner	Medipal Alcohol Wipes	Sani-Hands Instant Hand Sanitizing Wipes
Dimethyl Benzyl Ammonium Chlorides 0.125%	-	Sodium Hypochlorite 0.55%
Dimethyl Benzyl Ammonium Chlorides 0.14%	PDI Easy Screen Cleaning Wipe	Super Sani-Cloth Germicidal Wipe
Ethyl Alcohol 54%-66v/v + N-Propanol 9% -11% v/v	Peracetic Acid Solution 0.2%	Viraguard
Formula 409 Glass and Surface Cleaner	Progressive Products WipesPlus®	Virex II 256 One-Step Disinfectant Cleaner

CK65 AND CT60XP MOBILE COMPUTERS WITH DRH:

3% Hydrogen Peroxide and 97% Water Solution	Gentle Dish Soap and Water	Progressive Products WipesPlus
Alcowipe	Isopropyl Alcohol 55%	Sani Professional Disinfecting Multi-Surface Wipes
Azowipe	Isopropyl Alcohol Wipes 70% (IPA 70)	Sani-Cloth AF3 Germicidal Disposable Wipe
Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes	Medical Hydrogen Peroxide 3%	Sani-Cloth HB Sani-Germicidal Disposable Wipe
Clorox Healthcare Multi-Surface Quat Alcohol Wipes	Medipal Alcohol Wipes	Sani-Cloth Plus Germicidal Disposable Cloth
Dimension 256 Neutral Disinfectant Cleaner	Oxivir Tb Wipes	Sani-Hands Instant Hand Sanitizing Wipes
Dimethyl Benzyl Ammonium Chlorides 0.125%	PDI Easy Screen Cleaning Wipe	Super Sani-Cloth Germicidal Wipe
Dimethyl Benzyl Ammonium Chlorides 0.14%	Peracetic Acid Solution 0.2%	Viraguard
Ethyl Alcohol 54%-66v/v + N-Propanol 9% -11% v/v	Medicinal Alcohol 75%	Virex II 256 One-Step Disinfectant Cleaner

DESKTOP PRINTERS WITH DRH: (Excludes PC45)

Ammonium Chloride <10%
Gentle Dish Soap and Water
Isopropyl Alcohol Wipes 70% (IPA 70)
PDI Alcohol Prep Pads
Sani-Cloth HB Sani-Germicidal Disposable Wipe
Sani-Cloth Plus Germicidal Disposable Cloth
Sodium Hypochlorite <6%
Spartan Super HDQL 10
Super Sani-Cloth Germicidal Wipe
Surgipath® Cloro-Wipe Towelette
Viraguard
Virex

PC45 DESKTOP PRINTERS WITH DRH

3% Hydrogen Peroxide and 97% Water Solution	Medical Hydrogen Peroxide 3%
10% Bleach (Sodium Hypochlorite 0.55%) and 90% Water Solution	PDI Easy Screen Cleaning Wipe
Clorox Dispatch Hospital Cleaner Disinfectant Towels with Bleach	PDI Sani-Cloth AF3 Germicidal Disposable Wipe
Clorox Healthcare Bleach Germicidal Wipes	Peracetic Acid Solution 0.2%
Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes	Sani-Cloth Bleach Germicidal Disposable Wipe
Diversey Dimension 256 Neutral Disinfectant Cleaner	Sani-Cloth HB Sani-Germicidal Disposable Wipe
Diversey Oxivir Tb Wipes	Sani-Cloth Plus Germicidal Disposable Cloth
Ethyl Alcohol 54%-66v/v + N-Propanol 9% -11% v/v	Sani-Hands Instant Hand Sanitizing Wipes
Formula 409 Glass and Surface Cleaner	Sodium Hypochlorite <6%
Isopropyl Alcohol 55%	Sodium Hypochlorite solution 0.05% (500PPM)
Isopropyl Alcohol Wipes 70% (IPA 70)	Super Sani-Cloth Germicidal Wipe
Medical Alcohol 75%	Virex II 256 One-Step Disinfectant Cleaner

CLEANING PROCEDURE

Important: Please follow your organization's cleaning policies and instructions provided by the disinfectant chemical manufacturer to determine the frequency and duration with which the following cleaning procedure should be performed.

Cleaning instructions

1. Turn off the device.
2. Ensure that the battery is properly locked into the unit to prevent liquid from entering the electronics.
3. Apply the approved cleaning solutions from the above list to a sterile cloth or use the wipes provided.
4. **Do not** submerge the product in water or disinfectant cleaner; wipe outer surfaces only.
5. Wipe all plastic surfaces of the Honeywell device with the moistened cloth or wipes for the time required by the disinfectant solution.
 - **Do not** wipe or apply disinfectant chemicals to any electrical contacts, battery charge contacts or metal connectors, as these connectors may become corroded with repeated cleaning.
 - Avoid pooling the cleaning solution on any part of the product to prevent the liquid from gaining access to the inside of the device.
 - The display window, keyboard, triggers and connector areas require the most attention to avoid liquid entering the device.
 - Keep a dry sterile cloth ready to dry the device after cleaning.
6. Use a cotton-tipped swab to clean between the keys on the keyboard and in other recessed areas of the device.
7. The cradle contacts should be cleaned monthly with a cotton-tipped swab dipped in isopropyl alcohol to provide the ideal charger-to-battery contact.

CLEANING THE DISPLAY OR LENS AFTER DISINFECTING

After cleaning and disinfecting the Honeywell device, the display or lens area may be cleaned with a glass cleaner to remove any streaking left from the previous cleaning process.

1. Lightly moisten a lint-free cloth with the approved glass cleaners included above.
2. Wipe the display or lens area of the device briefly and quickly wipe dry to remove streaks or spots.

Contact a Honeywell Solutions Expert today!
Call 1-800-934-3163.

For more information

automation.honeywell.com

Honeywell Industrial Automation

855 S Mint St
Charlotte, NC 28202
800-582-4263
www.honeywell.com

TO LEARN MORE ABOUT HONEYWELL SOLUTIONS

Customers are encouraged to consult their Honeywell product user guide for specific product information on use, care and maintenance.

The following are links to learn more about Honeywell solutions.

1. **Honeywell Retail Solutions**
<https://sps.honeywell.com/us/en/industries/retail>
2. **Honeywell DC and Warehouse Solutions**
<https://sps.honeywell.com/us/en/industries/distribution-centers>
3. **Honeywell Transportation and Logistics Solutions**
<https://sps.honeywell.com/us/en/industries/transportation-logistics>
4. **Honeywell Healthcare Solutions**
<https://sps.honeywell.com/us/en/industries/healthcare-life-sciences>
5. **Honeywell MarketPlace (Online App Marketplace)**
<https://marketplace.honeywell.com/home>